



THANK YOU!

Thank you for choosing Orange. You are now a member of the 'Legendary British Guitar Amplifier' owners club!

Since 1968 when the company was founded, Orange has been a pioneering force in the guitar amplification industry. Today, with a team of the world's finest amplifier engineers, Orange continues to push back the boundaries of conventional tube amplifier design.

Our commitment to craftsmanship and quality control has allowed our amplifiers to stand the test of time, giving their owners as much pleasure now, as the day they were bought. To maintain this level of excellence, each Orange amplifier is put through many rigorous test procedures before leaving the factory.

The warmth, tonal quality and rich harmonics generated by a valve amplifier cannot be reproduced by 'artificial' means. Many guitarists have reached the same conclusion: neither the transistor nor microchip is a suitable alternative to valve technology.

This booklet contains valuable technical and safety information. Please take the time to read this manual as the information may enhance the sound and performance of your amplifier. We are confident that you will be delighted with your new purchase and that it will provide you with many years of enjoyment.



ENGLISH

CONTENTS

CONTENTS 3

CONTACT DETAILS 4

IMPORTANT SAFETY INFORMATION 5

USING YOUR AMPLIFIER..... 7

FEATURES 9

VALVES AND FUSES CAN FAIL AT ANY TIME! 11

FREE EXTENDED WARRANTY OFFER..... 11



ENGLISH



CONTACT DETAILS

Orange Amplifiers
OMEC House
108 Ripon Way
Borehamwood
Hertfordshire
WD6 2JA
ENGLAND

Tel: +44 20 8905 2828
Fax: +44 20 8905 2868
info@omec.com

Orange USA
2065 Peachtree Industrial Ct.
Suite 208
Atlanta, GA 30341
USA

Tel: 1-404-303-8196
Fax: 1-404-303-7176
info@orangeusa.com



ENGLISH

IMPORTANT SAFETY INFORMATION



ENGLISH



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of un-insulated 'dangerous voltage' within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons. Terminals labelled as

"Speaker Outputs" must be connected to a speaker cabinet of the designated load rating using an un-shielded two conductor cable for speaker use at all times during operation



The exclamation point within an equilateral triangle and "WARNING" are intended to alert the user to the presence of important operating instructions. Failure to heed the instructions will result in severe injury or death.

- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near liquid.
- Clean only with dry cloth.

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades, one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Servicing: Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards.
- Refer all servicing to qualified service personnel.
- Damage Requiring Service: Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions: (a) When the power-supply cord or plug is damaged; (b) If liquid has been spilled, or objects have fallen into the product; (c) If the product has been exposed to rain or water; (d) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation; (e) if the product has been dropped or damaged in any way; (f) when the product exhibits a distinct change in performance - this indicates a need for service.
- Replacement Parts: When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.





This Orange Amplifier conforms to UL Standard 60065 for Audio, Video and Similar Electronic Apparatus - Safety Requirements;

Certified to CAN/CSA-C22.2 No. 60065-03; IEC 60065 2001 + A1:2005



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



ENGLISH

USING YOUR AMPLIFIER

IMPORTANT!

For countries or regions with a mains voltage of 115v or 120v, please switch the small, red mains selector to 115v or 120v and replace the fuse in the black pull out fuse tray, below the mains inlet, with the 120v version supplied.

For countries or regions with a mains voltage of 230v, please switch the small, red mains selector to 230v and replace the fuse in the black pull out fuse tray, below the mains inlet, with the 230v version supplied.

Mains Fuse:

T1 Amp for 100v. (Japan Only)

T1 Amp for 120v.

T500MA for 230v.



ENGLISH

FEATURES

1. Connect the amplifier to a speaker cabinet of the correct impedance.

Connect 1 x 16ohm cabinet to the 16ohm speaker output jack socket.

Connect 1 x 8ohm cabinet to either of the 8ohm speaker output jack socket.

Connect 2 x 16ohm cabinets to both of the 8ohm speaker output jack sockets.

2. Connect the amplifier to a mains supply of the correct voltage as marked on the amplifier.
Make sure that the HALF/STBY/FULL output switch is in the Standby (middle) position before switching the power switch to the ON position.

3.  GAIN CONTROL.

The gain control adjusts the gain. High levels of gain will heavily overdrive the pre-amp and may sometimes be uncontrollable, especially when used at high volume levels!

4.  BASS CONTROL

The Bass control adjusts the level of bass after the pre-amp stages and before the FX Loop.

5.  MIDDLE CONTROL

The Middle control adjusts the level of midrange after the pre-amp stages and before the FX Loop.

6.  TREBLE CONTROL

The Treble control adjusts the level of treble after the pre-amp stages and before the FX Loop.

7.  VOLUME CONTROL.

The volume control adjusts the output volume.

High levels of volume will heavily overdrive the output stage.





8. OUTPUT SWITCH. (HALF/STBY/FULL)

The output switch (found next to the power switch on front of amplifier) runs the valves at a low plate voltage (reducing output power) in the HALF position and at a higher plate voltage (increasing output power) in the FULL position.

The middle position is the standby position.

This switch should be in the standby position for around two minutes after first powering up the amplifier!

9. EFFECTS LOOP SEND AND RETURN JACK SOCKETS.

The effects loop, send and return jack sockets are intended for use with outboard pedals or rack equipment such as delay, reverb and chorus etc.

Effects such as wah-wah, fuzz, distortion etc, would probably be best placed between the guitar and amplifier input.

The effects loop is wired in series with the pre-amp signal and is completely valve driven.

10. VALVES.

The OR15 contains 3 x 12AX7 (ECC83) and 1 x 12AT7 (ECC81) in the pre-amp and effects loop and 2 x EL84 in the output stage.

11. HT FUSE. (T250MA)

Please contact a qualified service technician if this fuse fails!



VALVES AND FUSES CAN FAIL AT ANY TIME!

From time to time output and preamp valves may fail. We suggest that output valves are changed at least once a year and that all class AB models (50 watts and above) will benefit from having the bias checked and adjusted. Bias checking must be carried out by a qualified engineer.

Orange amps are protected from damage caused by valve failure and inconsistent mains voltage by various fuses. We recommend that Orange users have a set of spare valves and fuses.

For more information on maintenance and for accessories and spares, please visit

www.orangeamps.com

FREE EXTENDED WARRANTY OFFER

Orange amplifiers are under warranty for one year subject to consumer protection laws in the country of purchase and distributor's terms and conditions, an additional year can be added by registering your purchase at www.orangeamps.com

Valves and speakers supplied with an Orange amp or purchased separately at our online store are covered for 90 days from the date of purchase.

The warranty status of any Orange product is subject to its being used for its intended purpose in suitable conditions. As the manufacturer we reserve the right to refuse to warranty any Orange product which has been misused in any way whatsoever.